




60'S TELECASTER w/Bigsby 0256800




60'S TELECASTER w/Bigsby 0256800

REF.#	P/N	DESCRIPTION
1	080249	BODY(W/Bound), 60's Telecaster Bigsby
2	080250	NECK, 60's Telecaster
3	080127	SD91-05M, Ni (set of 6)
	080130	SCREW 2.4 X 10 Ni, T.KEY MTG
4	080176	NUT 42.5x3.1x5.5 UREA
5	010389	S.GUIDE Ni
	080186	SCREW, 2.1x10 Ni, SG, VT PANEL MTG
6	264629	NECK MTG PLATE NPF, Cr
	264632	SCREW, 4.5x45 Ni, NECK SET PLATE MTG
7	080251	PICKGUARD, TL-800 MINT(AGED)
	264614	SCREW, 2.7x13 Ni, PICKGUARD & VT PANEL MTG
8	080244	PICKUP W/CHROME COVER(CTL50)
	264965	SCREW, 2.4x25 Ni, RHY PICKUP MTG
9	080245	PICKUP, BRIDGE(CTL50)
	080252	SCREW, 4.0 x 16 Ni, LEAD PICKUP PLATE MTG
10	080246	PLATE, LEAD PICKUP MTG
11	264917	END PIN, Ni
	080243	SCREW, 3.5x12 Ni, END PIN MTG
12	264929	CONTROL 250KA (16ø)
13	264975	CONTROL PANEL
14	264857	SWITCH, 3WAY, VLX-3
15	264979	KNOB, SWITCH, BLACK, HAT
16	264983	KNOB, FLAT, VOLUME & TONE
17	080116	CAPACITOR, 0.047µF Maira
18	080302	CAPACITOR, 0.01µF Maira
19	080124	JACK, OPEN SMALL
20	264981	FERRULE, JACK, CR
21	264237	BRIDGE ASSEMBLY
22	264238	BRIDGE SECTION(1st/2nd)
23	264239	BRIDGE SECTION(3rd/4th)
24	264240	BRIDGE SECTION(5th/6th)
25	264241	SCREW, HEIGHT ADJ 3x8 (1st/6th)
26	264242	SCREW, HEIGHT ADJ3X10(2nd-5th)
27	264243	SCREW, LENGTH ADJ 3x15
28	264244	SPRING, BRIDGE SECTION
	264245	THIMBLE-BRIDGE, BODY
29	264246	CHANNEL ASSY, ADJUSTABLE BRIDGE
	264247	SCREW, HEIGHT ADJUSTMENT BRIDGE ASSY
30	0595-B5FENCT	BIGSBY B5F VIBRATO UNIT w/F-logo Chrome

60'S TELECASTER w/Bigsby 0256800 WIRING DIAGRAM




21 BRIDGE ASSEMBLY



60'S TELECASTER w/Bigsby 0256800

SWITCH & CONTROL FUNCTION



DETAIL
3 WAY SWITCH

3 WAY SWITCH POSITION			
 3	 2	 1	← 3 WAY SWITCH POSITION
			← NECK PICKUP
			← BRIDGE PICKUP
 PICKUP IS ON		 PICKUP IS OFF	

