


CLASSIC PLAYER STRATOCASTER HH ® (014-1120-XXX)

PARTS LAYOUT



CLASSIC PLAYER STRATOCASTER HH ® (014-1120-XXX)


PARTS LIST

REF #	DESCRIPTION	PART NUMBER
1	BODY CLSC PLYR STRAT MRC BLU B&P	7704770568
2	NECK CLSC PLYR STRAT HH RW PNT	7704769000
3	KEY GTR 70's F SHORT RH CHR	0990822100
4	BUSHING FOR KEY	0990822100
5	SCRW SMAB 3x3/8 RHP NI	0011357049
6	STRING GUIDE NICKEL	0994910000
7	SCRW SMA 3x5/8 RHP NI	0011358049
8	PICKGUARD YURI STRAT HH BWB BVL	7700975012
9	SCRW SMAB 4x1/2 OHP NI	0015578049
10	PICKUP ASSY, TWIN HEAD WR ZEBRA NK	0096283020
11	PICKUP ASSY, TWIN HEAD WR ZEBRA BRG	0096284020
12	SPRING HB MTG 3/4"	0050167049
13	SCREW M#3-48x13/16 RHP#4 HD ZA	0050166049
14	SWITCH 5 POS DISC 4 POL	0992251000
15	KNOB PU SWCH VINT AGD	0994938000
16	KNOB STRAT VOL AGED WHT	0991368000
17	CONTROL 500K VOL. 3/8 SPLIT	0990834000
18	WASHER LOCK INTL 3/8 X .687	0016436049
19	NUT HEX 3/8-32x3/32 TK NI	0016352049
20	KNOB STRAT TONE AGD WHT	0991369000
21	JACK PHONE 1/4 - OUTPUT	0047329049
22	WASHER LOCK INTL 3/8 X .687	0016436049
23	NUT HEX 3/8-32x3/32 TK NI	0016352049
24	FERRULE JACK CHROME	0991940100
25	BRIDGE ASSY, 2 PT. TREM	0072253000
26	SCREW MACHINE-BRIDGE PIVOT	0028957049
27	INSERT SCREW MACH,BRIDGE PIVOT	0028958049
28	SPRING TREMOLO TENSION, NI	0050922000
29	SPRING, TREMOLO CLAW NICKEL	0050918000
30	SCRW SMA 8x1-3/4 OHP NI	0015636049
31	BACK COVER STRAT SPRING BWB	0081420000
32	PLATE NECK "CUST. SHOP DESIGNED" CHRM	0072246000
33	BUTTON STRAP NI 0.156	0994915000
34	SCRW SMAB 5x1 OHP NI	0015610049



CLASSIC PLAYER STRATOCASTER HH ® (014-1120-XXX)

WIRING DIAGRAM



CLASSIC PLAYER STRATOCASTER HH® (014-1120-XXX)

SWITCH & CONTROL FUNCTION

5 WAY SWITCH POSITION					
					SWITCH POSITION
T1	T1	T1 & T2	T2	T2	← TONE CONTROL
					← NECK PICKUP (A) ← NECK PICKUP (B)
					← BRIDGE PICKUP (C) ← BRIDGE PICKUP (D)

	PICKUP IS ON
	PICKUP IS OFF
A	PICKUP (NECK)
C	PICKUP (BRIDGE)

