


ROAD WORN PLAYER STRATOCASTER (01310623XX)

PARTS LAYOUT



ROAD WORN PLAYER STRATOCASTER (01310623XX)

PARTS LIST

REF#	DESCRIPTION	PART NUMBER
1	BODY ROAD WORN PLAYER 2TS RELIC	0080848516
1	BODY ROAD WORN PLAYER OWT RELIC	0080848590
2	NECK ROAD WORN PLAYER STRAT MN RELIC	0080849000
3	KEY GTR DUAL PIN MNT RDWN LIGHT	0037429800
4	BUSHING KEYS RDWN LIGHT	0053107800
5	WASHER KEYS RDWN LIGHT	0053106800
6	STRING GUIDE NCKL RDWN	0010389400
7	SCREW SMAB 3 X 3/8 RHP NCKL RDWN	0011357400
8	PICKGUARD STRAT B/W/B RDWN LIGHT	0011240800
9	SCREW SMA 4 X 1/2 OHP NI RDWN	0015578400
10	KNOB PICKUP SWITCH BLK RDWN LIGHT	0013267800
11	SWITCH 5 WAY LEVER RDWN	0053291800
12	SCREW MA 6-32 X 5/8 RH ZARTAN RDWN	0021417400
13	KNOB STRAT VOLUME BLACK RDWN LIGHT	0056147800
14	CONTROL 250K 10% TPR SPLIT	0990830000
15	NUT HEX 3/8-32 X 3/32 TK NI RDWN	0016352400
16	WASHER LCK INTL 3/8 X .500 X.020 NI	0022384049
17	KNOB STRAT TONE BLACK RDWN LIGHT	0056146800
18	CAPACITOR MPF RDL .022MF 250V 10%	0024832049
19	FERRULE JACK CHROME STD STRAT RDWN	0033023800
20	JACK PHONE 1/4 OUTPUT RDWN	0047329400
21	BRIDGE ASSY STD RH RDWN	0071014401
22	SCREW WD 6 X 1-1/4 RHP ZARTAN CH RDWN LIGHT	0021421800
23	SPRING TREMOLO TENSION NI	0050922000
24	BRIDGE PICKUP TEX SPCL BLACK RDWN LIGHT	0080942800
25	SCREW 6-32 X 3/4 RHP ZA RDWN	0048631400
26	TUBING LATEX CUT .300 X 1/8D X 1/4OD	0994916000
27	MIDDLE PICKUP TEX SPCL BLACK RDWN LIGHT	0080941800
28	NECK PICKUP TEX SPCL BLACK RDWN LIGHT	0080940800
29	NECK PLATE VINT TELE RDWN LIGHT	0033024800
30	SCREW SMA 8 X 1-3/4 OHP NKL RDWN	0015636400
31	SCREW SMA 8 X 1-3/4 OHP NKL	0015636049
32	SPRING TREMOLO CLAW NICKEL	0050918000
33	BACK PLATE STRAT RH B/W/B RELIC	0055274800
34	STRAP BUTTON RDWN	0012344400
35	SCREW SMAB 5 X 1 OHP NI RDWN	0015610400

* = NOT PICTURED IN DIAGRAM




PARTS LIST

* = NOT PICTURED IN DIAGRAM

ROAD WORN PLAYER STRATOCASTER (01310623XX)

WIRING ASSEMBLY



ROAD WORN PLAYER STRATOCASTER (01310623XX)

SWITCH AND CONTROL FUNCTION

5 WAY SWITCH POSITION					
					SWITCH POSITION
T1	T1 & T2	T2	T2	NO TONE	← CONTROL
					← NECK PICKUP
					← MIDDLE PICKUP
					← BRIDGE PICKUP
PICKUP IS ON PICKUP IS OFF				INDICATES POSITION OF 5 WAY SWITCH	

